



## Office & Showroom

Shanghai  
Tel : (86) 21 6278 8888

Beijing  
Tel : (86) 10 8521 7588

Guangzhou  
Tel : (86) 20 3892 2422

Shenzhen  
Tel : (86) 769 8203 1018

Dongguan  
Tel : (86) 769 8203 1111

Hong Kong  
Tel : (852) 2828 6888

Singapore  
Tel : (65) 6817 8750

## 分行及展厅

上海  
电话 : (86) 21 6278 8888

北京  
电话 : (86) 10 8521 7588

广州  
电话 : (86) 20 3892 2422

深圳  
电话 : (86) 769 8203 1018

东莞  
电话 : (86) 769 8203 1111

香港  
电话 : (852) 2828 6888

新加坡  
电话 : (65) 6817 8750

## Service Hotline

Mainland China : (86) 800 820 6073 | (86) 400 686 8073  
Hong Kong & Asia Pacific : (852) 2828 6000

## 客户服务热线


中国大陆 : (86) 800 820 6073 | (86) 400 686 8073  
香港及亚太区 : (852) 2828 6000

Rhythm  $\beta$



INSTRUCTION





## Rhythm: Where Comfort Meets Class

奕凡: 典雅舒适 气派非凡



### a Tilt Tension Control

Adjust tension by pulling out telescoping knob and turning clockwise to increase, counterclockwise to decrease.

#### 拉力调节

通过旋钮调节倾仰拉力强度，顺时针旋转为增加倾仰力度，逆时针旋转为减小倾仰力度。



### b Seat Height Adjustment

Raise seat height by lifting weight and pulling on lever. Lower seat height by lifting on lever while seated.

#### 座高调节

起身并拉动操纵杆来提高座椅高度；坐下时抬起操纵杆，降低座椅高度。



### c Tilt Lock

Slide tilt lever back to preferred position, Lift lever under seat to lock. Press tilt lever to release lock.

#### 倾仰锁定

当座椅向后倾仰至您满意的角度时，向上拉动调节手柄从而完成位置锁定。椅背需返回原位时，下压倾仰调节手柄即可。



Rhythm  $\beta$  presents a sleek design in leather upholstery to fit you like a glove. Made for leaders, it creates a timeless, cohesive aesthetic that offers ample space and true comfort.

奕凡 $\beta$ 采用上乘皮革材质，配以柔滑设计的包覆工艺，圆润的座椅外形宛若双手拥抱，能让您享受泰然自若的舒适。专为领导者提供宽大和极至舒适的座感空间、打造永恒俊朗的美感。